

PnP Setup for wifiCAMit_Dome with 3JTech wifi Router

Quick Installation Guide

With proprietary wifiDHCP technology, the wifiCAMit_Dome can be plug and play with regards to its WIFI settings if you use it in conjunction with 3JTech's Dedicated Wifi Router (DWR). Please follow the procedures below to set up your wireless wifiCAMit_Dome IP Camera with DWR.

■ Connecting the wifiCAMit_Dome to the DWR

- 1) Connect the power cable to the power jack of DWR.
- 2) Connect the wifiCAMit_Dome to a LAN port of DWR via the RJ45 cable.
- 3) Connect the power cable to RJ22 jack of the wifiCAMit_Dome.
- 4) The LED on the back of the wifiCAMit_Dome will flash when the SSID and WEP Key of the DWR are passed to the wifiCAMit_Dome successfully.
- 5) Remove the power cable of the camera and RJ45 cable.
- 6) Switch the button inside of the camera into **"Wireless"** position.
- 7) Plug in the power cable of the wifiCAMit_Dome.

STEP 1.



NOTE : One time only before resetting the wifiRouter to the factory default settings.

STEP 2.

