

# PnP Setup for wifiCAMit with 3JTech wifi Router

## Quick Installation Guide

With proprietary wifiDHCP technology, the wifiCAMit can be plug and play with regards to its WIFI settings if you use it in conjunction with 3JTech's Dedicated Wifi Router (DWR). Please follow the procedures below to set up your wireless wifiCAMit IP Camera with DWR.

### ■ Connecting the wifiCAMit to the DWR

- 1) Connect the power cable to the power jack of DWR.
- 2) Connect the wifiCAMit to a LAN port of DWR via the RJ45 cable.
- 3) Connect the power cable to RJ22 jack of the wifiCAMit.
- 4) The LED on the back of the wifiCAMit will flash when the SSID and WEP Key of the DWR are passed to the wifiCAMit successfully.
- 5) Remove the power cable of the camera and RJ45 cable.
- 6) Switch the button located at the left side of the camera into “**Wireless**” position.
- 7) Plug in the power cable of the wifiCAMit.

### STEP 1.



**NOTE :** One time only before resetting the wifiRouter to the factory default settings.

**STEP 2.**

